

Course: PG Paathshala-Biophysics

Paper 3: Techniques in Molecular Biophysics

Module 15: Gas chromatography: principles and application

TABLE OF CONTENTS

1. Learning Outcomes
 2. Introduction and overview of principle
 3. Principle of gas chromatography
 4. The gas chromatographic system: components
 - 4.1. Injection port
 - 4.2. Carrier gas
 - 4.3. Column
 - 4.4. Detectors
 5. Applications of gas chromatography
 6. Factors affecting gas chromatography
 7. Illustrative methodology of gas chromatography
-

1. Learning outcomes: After completing this chapter, the student shall be able to:

- b. Describe the principle of gas chromatography**
- c. List the various components of gas chromatographic system**
- d. Describe the process of gas chromatography**
- e. List the different types of detectors used**
- f. List different applications of gas chromatography**

1. Introduction: chromatographic techniques are used widely across scientific disciplines and in industry for multiple applications, some of which may even be overlapping. Broadly classified into planar and column chromatography, the general principle involves the separation of components (i.e. analytes of interest) of a mixture (of widely varying constitution e.g. peptides, lipids, pigments etc.) based on their relative solubility in, and hence movement through “phases” i.e. mobile and stationary, used in the technique. Further, chromatography is divided into gas and

liquid based on the nature of the mobile phase. When the mobile phase is liquid then the technique is referred to as “liquid chromatography” and when the mobile phase is gaseous then as “gas chromatography” (GC). The idea of using gas chromatography as an analytical tool was originally introduced by Martin and Synge in the 1940s who then demonstrated its utility by separating a mixture of fatty acids using GC.

Gas chromatography is a highly sensitive technique that is routinely used in industrial laboratories for quantification of compounds, quality control and in forensic laboratories for detection of many chemicals that are present in extremely small amounts.

The mobile phase in gas chromatography is an inert gas that does not interact with the analytes in the mixture to be separated. If the gas phase moves over a solid stationary phase, then it is called “gas solid chromatography”. If the gas moves over a non-volatile liquid phase coated over a support, then it is referred to as “gas-liquid chromatography”.

2. Principle of gas chromatography

The underlying premise of separation using GC is based on the presence of analytes that are volatile (or modified i.e. *derivatized* to be volatile) at the temperatures at the point of injection. These analytes are typically dissolved in a solvent, and small amounts (typically in microliters) are injected into the gas chromatograph through an inlet. The separation will depend how strongly the compounds in the injected sample interact with the stationary phase. A stronger interaction means a longer interaction with the stationary phase and hence a longer time to migrate through the column and exit the column.


Each of the components of the sample leaves the column at a certain time called its “*retention time*”. The exit of analytes from the column is perceived by a detector and converted into electrical signals for each of the analytes exiting the column which are visible as peaks on the recorded output of the

process. This output is called the “*chromatogram*”. There are many kinds of detectors(D) used in gas chromatography e.g. electron capture (ECD), flame ionization (FID), thermal couple (TCD), Nitrogen-Phosphorus (NPD) and mass spectrometry (MS).

3. The gas chromatographic system:

Overview: the system consists of an injection port, an oven containing the column which may operate isothermally or maybe temperature programmed, an exit port and a detector that detects the analytes coming out of the column. In addition, gas cylinders for maintaining the flow of the mobile phase i.e. gas, are also connected to the oven containing the column.

Figure 1a: Schematic diagram of a gas chromatographic system



Components:

4.1. Carrier gas: is the medium in which the sample mixture is carried along the column, and flows out. The carrier gas should be inert, should allow a sufficient detector response and from a practical

perspective, also be low-cost. The gases usually selected as carrier gases are helium or nitrogen although some other gases have also been used. Certain types of detectors such as the Flame Ionization Detector also need a source of combustion for the detector to function (i.e. the flame to be lighted). The gas used for this is hydrogen.

4.2: The injection port is where the sample is introduced into the column (i.e. the column head). In modern gas chromatographs, the port is usually heated so that sample injection and vaporization can take place simultaneously. The sample volumes typically injected are in the range of a few microliters through a rubber septum and into the vaporization chamber. Depending on whether the whole sample is needed (uncommon) for analysis or only a small amount is needed, the injection can be split less or split by means of a splitter that directs excess sample to a waste collector.

4.3. Column: the column is the heart of the gas chromatography based separation process. There are hundreds of types of columns available with varying chemical composition and lengths. They are broadly categorized into “packed” and “capillary”. In the initial decades of analytical gas chromatography, **packed columns** were used, in which a glass or metal (mostly stainless steel but also aluminium, copper, polytetrafluorethylene) column tubing is packed with small spherical inert supports (e.g. diatomaceous earth). The liquid phase adsorbs onto the surface of these beads in a thin layer. Packed columns have higher sample capacity¹. However, packed columns are usually are less efficient and have lower resolution as compared to capillary columns. They are often used for preparative work and gas analysis. Their inner diameters range from 1.5 mm to 6 mm. A category of micro-packed columns are also available. They are micro pore tubes having inner diameters ranging from 0.3-1 mm and at lengths varying from 1 to 15 m, packed with particles 0.007-0.3 mm in diameter.

¹ The amount of sample that can be applied to a column without overloading.

The other kind of columns, called “**capillary columns**” are more in use nowadays and consist of a tubing, the walls of which are coated with the stationary phase or an adsorbent layer, which supports the liquid phase. Stationary phase thickness is typically 0.25 microns. Capillary columns have a higher efficiency and hence better peak separation than packed columns. Capillary columns are categorized into “The Wall Coated Open Tubular (WCOT)” columns, “Support Coated Open Tubular” (SCOT) and the “Porous Layer Open Tubular (PLOT)” columns. Capillary columns have inner diameters ranging from 0.10 to 0.20 mm and lengths including 10 m, 15m, 30m, 50 m, upto 15 m depending on the inner diameter. A very efficient, popular type of WCOT column is the fused-silica wall-coated (FSWC) open tubular column that is chemically very inert and requires very small sample sizes.

The columns are typically packed or coated with solid material which could perform the role of adsorbent (Gas Solid chromatography), in which case the separation takes place by adsorption, or the solid material could be support for stationary phase (which is a non-volatile liquid), as in Gas Liquid Chromatography, coated on a granular material, in which case the separation takes place by absorption.


A vast array of solid and liquid stationary materials have evolved for use over time, numbering into hundreds. These are sometimes naturally occurring materials such as Kieselguhr (diatomaceous earth based, that contain polysilicic acid as hydrated amorphous silica with a porous structure and varying amounts of metal oxides of Fe, Al, Mg, Ca, Na, K) or synthetically created polymers such as Squalane, teflon. If a liquid is chosen as the stationary phase, it should dissolve all the components of the samples differentially, be practically non-volatile at the temperature of the column, be chemically inert and have high thermal stability. The liquid may be non-polar (e.g. silicone oils methylsilicone type), polar (polyethylene glycol, silicone oils with cyanopropyl groups) or of intermediate polarity

(e.g. phenyl methyl silicone phase, dinonyl phthalate). The organic compounds are also empirically classified based on their chromatographic separation from Class I (very polar) to Class V (non-polar).

The suitability of the packing/coating material of the column for analysis of the sample mixture will depend on the chemical (and occasionally, structural) nature of the analytes in the mixture so as to allow an interaction between the stationary phase so that retention times vary as per the respective degrees of interaction between the analyte and stationary phase. In case the analyte is polar, the stationary phase should be polar and if the analyte is non-polar, then a non-polar/less-polar stationary phase should be chosen. Since compounds vary in their polarity in the same mixture, a compromise is often made while choosing the stationary phase.

The stationary phases on the GC columns need to be conditioned and activated by allowing the mobile phase to flow over the column before the samples for analysis are applied onto the column for separation. Also, while using the columns, care must be taken to understand the robustness of the column chemicals with regard to its thermal stability and also the effect of certain corrosive chemicals that may poison the column (e.g. oxygen, chromic acid, potassium hydroxide, perfluoroacids). To minimize changes of such damage, a guard column can be installed ahead of the main column. Sometime trimming a few feet of the initial part of the column can remove the damaged section.

Fig 2: Types of GC columns and their stationary phases:




4.4 Detectors:

Analysis: The quantitative analysis of a given component is based upon evaluating the chromatographic peak, which is triangle-shaped when columns with filling are used; its surface is measured and divided by the total surface, in different percentages for different types of detectors. For capillary columns with good resolution, the signal takes the shape of straight lines and calculating the composition of the mixture is done in the order of succession, dividing each individual line by the total number of lines and using an adequate calibration curve, drawn upon determinations of known compounds

Mixture components can be identified by comparison using chromatographic standards – that are pure substances or known mixtures of components. In these cases, universal detectors may be used. For unknown mixtures, mass spectrometry is recommended.

In gas chromatography, the **area** under the peak is proportional to the concentration of the analyte.

Figure 3: Representative chromatogram of fatty acid profile in serum:



Detectors: A wide range of detectors are available that are linked to gas-chromatography systems and are of varying sensitivities and application. The background levels (i.e. noise) and interferences are very low because the carrier gases used in GC are transparent to most detectors. Some of the detectors available are able to detect a wide range of samples down to picogram limits. The key attributes of a detector are sensitivity [which is indicated by the limit of detection ² (LOD)], selectivity³ and dynamic range⁴. Finally, the detector may respond to the concentration of an analyte passing through it or to the mass of the analyte passing through it. The former is called *concentration-sensitive* detector and the latter, *mass sensitive detector*. One of the detector types linked to the GC instrument, the *thermal conductivity detector* (TCD), is the most commonly used *concentration-sensitive detector*.

² This is the minimum quantity of material than can be distinguished from background

³ the ratio of the amount of a compound that does not contain the selected property that generates the same signal as a compound with the selected functionality

⁴ the usable (operating) range over which the detector will generate a changing signal as the amount of analyte changes

The list below describes the most common types of detectors used in gas chromatography:

Type of detector	Type of response	Response characteristic	Destructive	LOD
Flame Ionization Detector	Universal to C*	Mass	Yes	1 pg/s
Thermal Conductivity Detector	Universal	Concentration	No	500 pg/ml
Electron Capture Detector	Selective	Concentration	No	5 fg/s
Nitrogen Phosphorous Detector	Selective	Mass	Yes	1 pg N/s
Flame Photometric Detector	Selective	Mass	Yes	0.1-1pg P or S /s
Mass Spectrometry	Both	Mass	Yes	.25 to 100 pg
Atomic Emission Detector	Both	Mass	Yes	0.1 ng-1 pg/s

*Carbon.

5. Applications of gas chromatography:

Gas chromatography has many applications, both quantitative and qualitative. These include:

- a. Environmental analysis: pesticides' analysis in water/vegetables, vehicle emissions
- b. Clinical medicine: blood alcohol, drugs (nicotine, opioids)
- c. Forensic medicine: explosives
- d. Consumer goods quality control
- e. Food analysis: fatty acid composition, flavor components of edible products
- f. Petrochemicals: petrol composition; solvent purity, gas refineries

6. **Factors to be considered during GC method development to optimize time of separation and optimum resolution⁵:**

- **Carrier gas flow rate** : an increase in flow rate shortens retention times but may decrease resolution
- **Temperature program heating rates**: very high column temperatures lead to loss of resolution; optimum separation and retention time are usually achieved with temperature gradients.
- **Column length , column diameter**: A longer column and thinner diameter improve resolution
- **Thickness of the stationary phase**: Standard thickness in capillary columns is 0.25 microns; thicker stationary phases increase sample capacity and retention time as well as improve resolution of early peaks.
- **Sample volumes**: the sensitivity of capillary column based gas chromatography also limits the sample volume that can be applied to the column; overloading the column can lead to tailing of peaks and poor resolution.

A modified gas chromatography technique, called “**Fast Gas chromatography**” is able to shorten analysis time without loss of resolution. The process typically uses shorter length columns e.g. 20m, with smaller internal diameters (i.d.) to shorten analysis times with good resolution.

⁵ Resolution is a measure of how well two elution peaks can be differentiated in a chromatographic separation.

- 7. Illustrative methodology of gas chromatography using the example of analysis of fatty acids in serum:** this method involves the conversion of fatty acids into their methyl esters so that they can be volatilized, extraction of the derivatized esters into an organic phase and analysis on a polar gas chromatographic capillary column.

PROTOCOL : Fatty Acid analysis in serum:

Step 1: Sample preparation and derivatization

Glassware Required:

- Borosilicate glass tubes with Teflon-lined screw caps

Reagents Required:


- Acetyl chloride
- HPLC grade methanol, chloroform, and toluene.
- Internal standard : undecanoate(C_{11}) FAME: 1 mg /ml of C_{11} in $CHCl_3$ (Chloroform HPLC grade)
- 2[6]di-tert-butyl-*p*-cresol(Butylated Hydroxytoluene (BHT)): 5mg of BHT/100 ml of methanol (HPLC grade)
- Potassium carbonate (K_2CO_3) : 6mg % in distilled water
- Nitrogen gas

PROCEDURE:

All glassware should be rinsed with chloroform-methanol 2:1 (v/v) and dried under nitrogen before starting the experiment.

Prepare a fresh solution containing methanol-toluene solution in the ratio of 4:1 methanol and toluene. Add internal standard(25 μl) and BHT(2.5 μl) per sample followed by acetyl chloride (e.g. for 20 samples, 40ml methanol + 10 ml toluene + 500 μl C₁₁ + 50 μl BHT + 2.5 ml acetyl chloride - mix acetyl chloride dropwise while keeping tube on low speed vortex to the other components!

IMPORTANT: CRITICAL AND HAZARDOUS STEP. Wear gloves and mask.)




Step 2: Gas chromatographic analysis: For the GC analysis a gas chromatograph equipped with a hydrogen flame ionization detector, split mode injector and the capillary column SP- 2560 (100 m x 0.25 mm; biscyanopropyl siloxane stationary phase) will be used.

The operating conditions will be: (temperatures, in ⁰ C): injector, 225; detector, 285; initial temp, 100; ramp, 3 ⁰ C/min; final temp, 240; hold 15 min. The split ratio will be set at: 200:1.

Reconstitute sample using 2-3 μl iso-octane. Take 1 μl of each FAME for GC analysis. A mixed FAME standard solution will be used to optimize the running protocol and identify the fatty acids before testing the FAMEs prepared from the samples. Individual isomers will be identified by comparing with known retention times relative to the internal standard, C11:0. Specific isomers are also identified by running the unmodified FAME mix/sample followed by one spiked with the individual FAME isomer of interest.

Precautions: The reagents used must be HPLC grade and glassware used must be clean and free of detergent. Ideally, use of plastic ware should be avoided or it should be ensured that it is inert to organic reagents used in the protocol. Also, all reactions are to be run in triplicates for ensuring data validity when running for research purposes etc. The gas used for combustion, i.e. hydrogen is highly inflammable and care should be taken to maintain appropriate pressures when operating the gas flow valves.




Summary:

The technique of gas chromatography provides a highly sensitive and specific measure for a numerous analytes that are thermally stable volatile and/or amenable to derivatization to compounds with such properties.

The flexibility and range offered by this technique is due to a number of reasons including the separation power of the columns of the wall-coated open tubular columns type and the resolution possible with the widely used capillary columns.

The analytical process is relatively fast, there is an immense range and specificities offered by the number of detectors that can be linked to the separation process.

The key variables affecting the resolution of the gas chromatographic system include the carrier gas flow rates, column type and stationary phase thickness, length of column, and temperature programs followed during the analytical process.



A Gateway to All Post Graduate Courses